



1. External Parts



1. External Parts

Item	Part Number	Description	Qty.
1	3.4.03.01.001	Hopper Lid	1
2	3.4.08.01.002	O-Ring - 18x2.2	3
3	2.1.3.39.0010	Air Tube	1
4	2.3.4.28.091	Panel - Left	1
5	Page 6	Draw Switch and Front Control Panel	1
6	Page 5	Dispensing Door and Beater	1
7	2.3.4.26.086	Panel - Lower Front	1
8	2.3.6.03.024	Splash Shield - Front Drip Tray	1
9	3.4.04.01.004	Front Drip Tray	1
10	3.3.05.03.005	Leg	4
11	3.6.11.044	Panel Screw	6
12	3.4.07.01.041	Bolt Hole Cover	6
13	3.4.04.02.003	Internal Drip Tray	1
14	2.3.4.30.075	Panel - Right	1
15	2.3.4.23.0118	Panel - Rear	1
16	3.1.03.04.009	Mix Low Sensor	1


2. Internal Parts



2. Internal Parts


Item	Part Number	Description	Qty.
1	2.1.1.03.0082	Hopper Assembly	1
2	3.1.02.13.020	Temperature Probe - PT100	2
3	Page 7	Control Box	1
4	2.1.1.06.0157	Cylinder Assembly	1
5	3.3.01.04.008	Motor - Beater	1
6	3.2.01.02.055	Primary Compressor	1
7	3.2.05.01.006	Capillary Tube	1
8	3.2.01.02.055-1	Start Component - Compressor	1
9	3.2.04.01.037	Thermal Expansion Valve	1
10	3.2.04.05.016	Filter Drier - Cylinder	1
11	3.2.04.06.005	High Pressure Switch	1
12	3.2.04.05.012	Copper Strainer Filter	1
13	3.2.04.04.076	Solenoid Valve Body	3
14	3.2.04.04.059	Solenoid Coil	3
15	3.2.04.07.001	Filter Drier	
16	3.2.03.03.006	Fan Motor	2
17	3.2.02.01.046	Main Condenser	1
18	3.3.04.02.001	Pulley - Beater Motor	1
19	3.3.04.01.005	Bushing - 1008-16	2
20	3.3.02.03.004	Coupling Drive	1
21	2.1.3.15.0009	Bracket - Gear Box	1
22	3.3.02.01.030	Gear Box	1
23	3.3.04.02.022	Pulley - Gear Box	1
24	Page 8	Electrical Box	1
25	3.3.03.01.022	Belt - Motor to Beater	1
26	3.1.01.08.025	Inverter	1

3. Dispensing Door and Beater




Item	Part Number	Description	Qty.
1	3.4.07.05.003	Gasket - Beater	1
2	3.4.02.02.010	Helix Beater Blade	1
3	2.1.1.25.0015	Double Helix Beater	1
4	3.4.05.01.001	Handle - Dispensing	1
5	2.1.3.26.0004	Seat - Handle	1
6	3.4.08.01.012	O-Ring - 3x1.5	1
7	3.6.39.008	Adjustment Screw - Handle	1
8	3.4.08.01.013	O-Ring - 5.2x1.9	3
9	2.1.3.27.0026	Retention Pin - Handle	1
10	3.4.05.02.012	Hand Screw	4
11	2.1.3.14.0030	Dispensing Door	1
12	3.4.05.03.001	Design Cap	1
13	2.1.3.02.0015	Prime Plug	1
14	2.1.3.01.0002	Draw Valve	1
15	3.4.08.01.006	O-Ring - 16.8x2.4	2
16	2.1.1.11.0013	Helix Beater Rod	1
17	3.4.01.03.013	Helix Beater Guide	1
18	3.4.08.02.007	Door Gasket	1

4. Draw Switch and Front Control Panel




Item	Part Number	Description	Qty.
1	2.3.4.36.033	Panel - Overhead Front	1
2	3.1.03.04.046	Reset Button	1
3	3.1.03.03.003	Power Switch	1
4	2.3.4.39.052	Panel - Overhead Bottom	1
5	2.3.4.37.041	Panel - Overhead Side	2
6	2.2.1.01.0049	Control Board	1
7	3.1.03.01.002	Micro Switch	1
8	3.4.07.06.008	Bracket - Micro Switch & Shaft & Spring	1
9	3.6.03.012	Spring - Shaft - Draw Switch	1
10	2.1.3.50.0073	Shaft - Draw Switch	1

5. Control Box




Item	Part Number	Description	Qty.
1	3.4.08.01.034	O-Ring - 31×2	2
2	2.1.1.23.0005	Blade - Hopper Agitator	1
3	2.1.1.12.0002	Agitator Assembly	1
4	2.1.4.02.017	Pulley - Hopper Agitator - Driven	1
5	920.2.09.0001	Belt - Hopper Agitator - 650mm	1
6	3.3.04.04.006	Pulley - Hopper Agitator - Drive	1
7	2.3.4.45.343	Bracket - Agitator Motor	1
8	3.3.01.01.062	Motor - Agitator	1

6. Control Box



Item	Part Number	Description	Qty.
1	3.1.02.08.012	Seat - Fuse	1
2	3.1.02.08.003	Fuse	1
3	2.2.1.01.0040	Power Board	1
4	3.1.01.03.029	Intermediate Relay - HH54P-L	1
5	3.1.01.03.031	Base - Relay - TP514X1-E	1
6	3.1.04.01.003	Ribbon Cable	1

7. Electrical Box



Item	Part Number	Description	Qty.
1	3.1.01.04.002	Transformer	1
2	3.1.01.01.010	Contactor	1